User Guide

# AroMicro



Scent is the revival memories and.

### Contents

ENHANCE YOUR ATMOSPHERE

DIAGRAM OF PARTS

**QUICK START** 

WHERE TO PLACE

INTENSITY CYCLES & CONSUMPTION

WARNINGS

TROUBLE SHOOTING

WARRANTY AND SUPPORT


# **Enhance Your Atmosphere**

Style your home with scent

Scent is the first thing people notice when they enter your home or business. Now you can style your home ambience with your favorite Aromatica oils using the most advanced scent technology. The AroMicro will forever change the way you use scent in your home or business.

With the AroMicro, you can create and control an exquisite scent experience adjusted perfectly to match the size and conditions of a room. You can also change the scent depending on your mood, occasions and time of day.

# Diagram of Parts



#### Quick start

- Please keep the machine vertically after installation, tilting or lying it down may cause the essential oil to spill out;if the circuit board is contaminated by the essential oil, the machine efficiency may be affected.
- 2.Do not modify, disassemble or repair the machine at will; if any malfunction occurs, please contact related technician in time.
- 3.This product is only applicable to our provided fragrance. Do not add other fragrance to avoid. damaging the machine; nor disassemble and clean it by yourself. The matched fragrance can be purchased separately for replacement.
- 4. Do NOT use or store the device above 70°C.

#### Attention:

- 1. 3.5h charging time is highly recommended.
- 2. Please take the fragrance out of machine and keep it covered when carrying the machine out.
- Power On/Off can be achieved by long press only.
- 4. Only use the matched formula fragrance.
- Do NOT use quick charger for device.















2. Twist off the bottle cap.



3. Screw the bottle cap.



4. Put it back to the machine.



5. Peel off the adhesive pad, and stick the machine on the wall



 Install the machine with clip, then clip it into the car vent

#### Where to Place

#### LOCATION

The AroMicro is designed to be placed in a small Place, cars vent or Truck. Do not place device on finely finished surface areas.

#### SCENTING COVERAGE

The AroMicro can be adjusted to scent an area ranging from 10 to 15 sq.ft (1 to 15sq.m)

#### DEVICE LOCATION

An important element of your scenting experience is to properly position the device in the room to ensure optimal performance.

Choose the location where the Aromatica oil molecules can use the natural airflow in a room. This is particularly important with air-conditioned spaces. The best location for the AroMicro is where there is good airflow.

Do not place the AroMicro near an HVAC return grill, exhaust, fan, or vent. Setting near open windows will cause the scent to escape the space. Work with the natural airflow of the space.

Try a variety of locations and settings until you are happy with scent coverage. Give the AroMicro a little time to adjust to the new location and setting before changing it again

## Intensity grade and consumption

- 1.Long press for power on/off; Short press for level switch.
- 2. Charging indicator:

Power off: When charging, light turns red, when fully charged, light turns blue.

Power on: light color will change according to the grade.



Vibration switch	In the power-on state, if sensing vibration, it stars working.
	In the power-on state, if sensing no vibration within 60s, it will enter standby mode.

#### Grade:

Grade	Color	Working time
L1	Purple	Mist for 5s, pause for 10mins
L2	Blue	Mist for 5s, pause for 5mins



#### WARNINGS

- Only use the power adapter supplied with the device.
- Never operate the diffuser if the power adapter is damaged.
- Do not use the diffuser if any part of the device is broken.
- NEVER attempt to service, disassemble, or repair the device in anyway, other than cleaning and refilling the Aromatica oil bottle.
- When moving the device always keep it upright, do not tilt and carry securely with both hands.
- Always place unit on a stable, level surface and ensure it is over 2' away from the ceiling.
- NEVER dilute oils with water or carrier oils.
- NEVER pour water in or on the device and never operate with wet hands.
- Do not cover the device with objects or material while in use.
- Ensure power adapter is never blocked when pugged in.
- Keep nose clear from the scent output at the top of the diffuser when the device is operating.
- ALWAYS keep out of reach of small children and pets.
- Store at room temperature 68-75 F (20-23 C), 30-35% Humidity

In the event of a problem or issue, please contact us at or info@aromatica360.com

# Trouble shooting

Before having the machine repaired, please try to diagnose the problem first with the bellow instructions

Symptom	Remedy
Does not diffuse	<ul> <li>Whether the machine is in "not working period". If yes, it won't spray.</li> <li>Check whether the air pump is damaged. If yes, replace it with a new one.</li> </ul>
Spray little	- Check whether the gasket is damaged or loose. Please adjust it or replace it with a new one. - Check whether the atomized core is plugged; clear it with alcohol or replace it with a new one
Oil spi <b>ll</b>	- Check whether the atomized head is damaged
Oil overflow	- Check whether the oil bottle is loose, please install it correctly - Check whether the gasket of the atomized head is damaged; if yes, please replace it with another one Please keep the machine vertical; Tilt or lie flatly will cause the oil overflow

Possible cause	Solution
Someone else is connected via Bluetooth to your device.     Phone is too far away from diffuser.	Reset the diffuser by holding down the power button till you hear 2 beeps. Reconnect to Bluetooth via the app on your phone.
1. The bottle is filled too high.	Make sure the oil does not exceed the max fill line.
1. The diffuser is designed to cycle the pump on and off and mists intermittently. 2. The time of the day is outside of the scheduled operating periods.	1. Turn your diffuser on and then wait a full cycle, 10 min. Diffuser light turns off during normal running cycle. 2. Check scheduling in the Scenting App.
	Turn diffuser off and contact customer care Info@aromatica360.com
	1. Someone else is connected via Bluetooth to your device. 2. Phone is too far away from diffuser.  1. The bottle is filled too high.  1. The diffuser is designed to cycle the pump on and off and mists intermittently. 2. The time of the day is outside of the scheduled

## Warranty and Support

All products designed by AromTech come with a 1-year limited warranty. Failure to use Aromatica360 branded oils may cause your diffuser to malfunction or not diffuse properly in which case warranty will be void. If you have any questions or issues please reach out to our customer care experts:

info@aromatica360.com

# AROMATICA LUXURIOUS SCENT SURROUNDING

aromatica360.COM

info@aromatica360.com